



### Backfill Requirements For Property Line Cleanout Installations

The property line cleanout/piping shall be laid on a firm bed of  $\frac{3}{4}$  inch base rock (before inspection).

Property line cleanout/piping shall have a minimum cover of 4 inches of  $\frac{3}{4}$  inch base-rock, then native dirt. The  $\frac{3}{4}$  inch base-rock shall be at jobsite and shall be installed after final inspection.